




**7779BK**

# **Brick Outdoor Waterproof Bluetooth® Speaker**


## **Instruction Manual**

---


### **Whats Included:**

- 1x Outdoor Waterproof Bluetooth Speaker
- 1x Type-C Charging Cable

### Top View:



### Side View:



## Functions:

1. Call Button
2. Vol-/Previous Track
3. Play/Pause
4. LED Indicator
5. Vol+/Next Track
6. Battery LED Indicator
7. Mode Button
8. Microphone
9. Aux Input Port
10. Type-C Charging Port
11. ON/OFF Switch

## Tech Specifications:

1. Playing Time: up to 4hrs at max volume
2. Charge Time: 5hrs (from 0-100%)
3. Pairing Name: "Brick"
4. Input: DC 5V/400mA

## Instructions:

(Be sure to fully charge the speaker before using for the first time)

### 1. Charging the Speaker:

- Connect the provided charging cable to a power source and to the Type-C input port(10) on the speaker.
- The LED indicator will glow RED when charging, and will turn OFF when fully charged.
- Speaker will beep three times and flash blue when the battery is low.

### 2. Bluetooth® Setup:

- Switch the ON/OFF Switch(11) to the ON position, the LED indicator(4) will flash BLUE and speaker will tone when in bluetooth standby mode.
- Turn on the Bluetooth function of the mobile device, Select the "Brick" pairing name.
- Speaker will tone and LED indicator will glow BLUE if successfully paired.
- Speaker will automatically pair if the mobile device has been paired before.
- Switch the ON/OFF Switch to the OFF position to turn off the device.

**\*\* If the speaker isn't connected to Bluetooth it will automatically power off after 5 minutes.**

### 3. Using the Speaker:

- Short press the Play/Pause Button(3) to pause or Play music.
- **"Vol+/Next track"(5):**
  - Long press - Increase volume
  - Short press - Next track.
- **"Vol-/Previous track"(2):**
  - Long press - Reduce volume
  - Short press - Previous track

### 4. Calling:

- Short press the Call Button(1) to answer or end the call.
- Long press the Call Button(1) to reject the call.

### 5. AUX Connection:

- Connect a AUX cable(NOT INCLUDED) to the 3.5mm Aux input port(9) of the speaker and mobile device to play music directly.

## Safety Precautions:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Never store or use this product in temperatures below 32°F(0°C) or above 115°F(45°C).
3. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles. Keep out of reach of children.
4. Do not use the device in excess of its output rating.
5. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or temperatures above 104°F may cause explosion.
10. Ensure that qualified service professionals use only identical replacement parts to ensure product safety.

## FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Note:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CAN ICES-3 (B) / NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada)

## Trouble Shooting:

| Issue                    | Reason                        | Solution                     |
|--------------------------|-------------------------------|------------------------------|
| Speaker will not turn ON | Low Battery                   | Charge Completely            |
| Bluetooth wont connect   | Distance is too far apart     | Bring devices closer         |
| No sound                 | Low volume/<br>Bad connection | Turn up volume or see above  |
| Cables arent working     | Bad connection                | Unplug & plug all the way in |

## IC Statement:

- This device contains licence-exempt transmitter (s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. (1) This device may not cause interference.
2. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. (1) L'appareil ne doit pas produire de brouillage;
2. (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radio Frequency Exposure Statement for IC:

This equipment complies with IC exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

Déclaration d'exposition aux radiofréquences pour IC:

Cet équipement est conforme aux limites d'exposition IC établies pour un environnement non contrôlé. Cet équipement peut être utilisé dans des conditions d'exposition portables.

Item: 7779BK

Imported to Australia by

NI Concept (003 408 991)

FCC ID: 2ABHA0121

IC: 31955-00006

Made in China