


USER MANUAL

7784 Split Apart Bluetooth Dual Speaker



What's in the box?

1. Speaker*1 pair
2. Type-C cable*1

Notice

Please read user manual carefully before any operations, and keep it for your records.

Safety Instructions

- Do not disassemble this product.
- This product is not a toy. Use extra caution while children are using this product.
- Keep the speaker away from direct sunlight, fire and high voltage equipment.
- Do not store the speaker inside a car during hot weather.
- Speaker shall not be exposed to excessive heat such as sunshine, fire or the like.
- Device may become warm while charging.
- Turn product completely off when plugging and unplugging into outlet for charging.
- Keep the product dry; do not place the product in damp places.

CAUTION

- Minimum distances 20 cm around the apparatus for sufficient ventilations
- Ventilation should not be impeded by covering the openings.
- No naked flame sources such as lighted candles should be placed on or near the apparatus;

Instruction



- ① Power /Mode button
- ② TF card slot
- ③ Aux in
- ④ LED indicator
- ⑤ Type-C charging port
- ⑥ Next track/Volume increase
- ⑦ Previous track/Volume decrease

Function	Operation	LED indicator
Power on	Press and hold the power button for 2s	Blue for 1s
Pairing mode	Enter pairing mode automatically after on	Flash blue
Power off	Press and hold the power button for 2s	Off
Volume +	Short press "+" button	Blue
Volume -	Short press "-" button	Blue
Next track	Press and hold "+" button for 1s	Blue
Previous track	Press and hold "-" button for 1s	Blue
Switch mode	Double press power /mode button	Flash blue
Play/pause	Short press power button	Flash blue

Unpairing / pairing; long press the "+" and "-" buttons in any one of this pair speakers at the same time

Charging the Speaker

1. Switch off the speaker before charging.
2. Plug the Type-C cable into the speaker charging port.
3. Plug the other end of charging cable into a computer or power adapter.
4. Plug the power adapter into a power outlet.
5. When charging the LED indicator will be solid on red, and will turn off automatically when fully charged.

Note: Please charge the speaker battery fully before use.

Pairing the speaker

1. Turn on the speaker by long pressing the power button for 2s.
2. The device's LED indicator will flash blue.
3. On the mobile device (smartphone/tablet) turn on the BT connection.
4. Select "Split Apart Speaker" in the available wireless devices on your mobile device.

TF card mode

Insert the TF Card (User-supplied) into the speaker, the speaker enter TF card mode, automatically play the audio in the card when power on.

Note: TF card supports WAV/FLAC/APE/MP3 format, with capacity smaller than or equal to 32GB.

AUX-in mode


Simply connect the speaker with your non-Bluetooth device via the 3.5 mm audio jack cable when the speaker power on.

Trouble shooting

The twin speakers will be connected to each other automatically when both are on.

If two speakers could not be connected to each other successfully, please manually pair them as per the following steps:

1. Turn on twin speakers, and do not pair any Bluetooth devices;
2. Press and hold "+" & "-" simultaneously on any one speaker, then you will hear a beep;
3. Then the twin speakers will connect to each other successfully;



Item: 7784BK
 Battery: 1200mAh 3.7V
 Input: 5V=1A

NI Concept (003 408 991)
 Made in China