


75mm

User Guide

Magnetic Power Bank



Thank you very much for choosing this product. Please read this guide carefully before use and keep it in a safe place for future reference.

Specifications

Input	5V/3A, 9V/2.22A, 12V/1.67A (USB-C)
Output	5V/3A, 9V/2.22A, 12V/1.67A (USB-C & USB-C cable)
Phone Wireless Output	5W/7.5W/10W/15W 2.5W for Apple Watch 5W for Qi TWS Earphone

Diagram


① Power Button

② Inserted USB-C Cable (20W)

③ 3-in-1 Wireless Charging Area
(15W MAX for mobile, 5W MAX for Qi TWS Earphone, 2.5W MAX for Apple Watch)

④ USB-C Input/Output (20W)

⑤ Coulomb-counting Algorithm Power Display Screen




Quickstart Guide

1. To Charge devices:

a) Charge your device via cable
Plug in your device to the USB-C port with cable, then your device will be charged.

b) Charge your devices with the inserted cable
Plug the USB-C port of the inserted cable to your device, then, your device will be charged.

c) Charge your devices wirelessly:
Snap your Qi-enabled device (mobile phone, earphone, Apple Watch, etc) magnetically to the powerbank to activate the wireless charging.



2. To Recharge Powerbank
Connect the included charging cable to 5V or 9V or 12V USB power source via the USB-C port.

Warning

If the power bank is to be left unused for a long period, please fully charge it every 6 months.

When using this product, basic precautions should always be followed, including the following:

- Before using your power bank for the first time, fully charge it.
- Keep your power bank dry and away from moisture and corrosive materials.
- Do not clean your power bank with harsh chemicals, soaps or detergents.
- Do not store device in high-temperature environment, including heat caused by intense sunlight or other forms of heat.
- Do not put power bank close to the fire, into the fire or water.
- Do not disassemble this device or attempt to re-purpose or modify it in any manner.
- To reduce the risk of injury, only charge the power bank on a hard non-flammable surface and do not leave unattended when charging.
- Be cautious of excessive drops, bumps, abrasions, or other impacts to this device.
- Use the power bank at a temperature between -10°C-50°C
- Never dispose of batteries in the garbage. Always take used batteries to your local battery-recycling center.

60mm