


PB1004

Radiant 5000 mAh Solar Power Bank

Instruction Manual

Whats Included:

- 1 x 5000 mAh Power Bank
- 1 x Type-C to Type-C Charging Cable



Product Overview:

1. USB waterproof plug
2. Indicators
3. Solar panel
4. USB-A Output 1
5. Type-C Input & Output
6. USB-A Output 2
7. LED Lights
8. Hook

Specifications:

1. Capacity: 5000mAh/3.7V/18.5Wh
2. Type-C Input & Output: 5V - 2A (max.)
3. Dual USB-A Outputs: 5V - 2A (Max.)
4. Input power: AC adapter/Computer USB
5. 2A Type-C charging cable

Instructions:

1. **LED light: long press to toggle through the settings: turn on-flash-off.**
2. **Indicator light: 1 green indicator will light up when the solar panel feels the sunshine light**
3. **Charging the Power Bank:**
 - a. Using your mobile, connect the cable to your phone's adapter. Using the Type-C connector, connect the other end of the cable to the IN port on the portable Power Bank. Plug the adaptor into the outlet to begin charging.
 - b. Using the Type-C connector, connect the cable to the outlet on your computer. Connect the other end of the cable to an IN port on the portable Power Bank. Make sure the computer is turned on to begin charging the portable Power Bank.
4. **Charging mobile phone and other electronic devices.**
 - a. The portable power device has 2 USB output ports which has the maximum output current of 2000mA.
 - b. Connect the charging cable to your mobile phone/device using the appropriate connector. Connect the other end of the cable to the OUT port of the portable Power Bank. Your mobile phone/device should display the status of charging.
 - c. Remove the charging cable from your mobile device when it's fully charged.

Safety Precautions:

WARNING - The following basic precautions should always be taken when using this product:

1. Read all the instructions before using the product.
 2. Charge the power bank fully before initial use. The device will only achieve full performance after completing 2 or 3 charge and discharge cycles.
 3. To reduce the risk of injury, supervision is required when the product is used near children.
 4. Do not expose the device to moisture.
 5. Do not use the device in excess of its output rating. Overloaded outputs above rating may result in fire or injury.
 6. Do not use the device if it has been damaged or modified.
 7. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or injury.
 8. Do not disassemble the device. Take it to a qualified service professional for service or repair. Incorrect reassembly may result in fire or injury.
 9. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 100°C (212°F) may cause explosion.
 10. Services must be performed by a qualified repair technician, using identical replacement parts only. This will ensure product safety.
 11. Please charge for a minimum of 3 hours before first use and at least once every three months thereafter. Make sure the cable is securely connected when charging. If the cable is not connected correctly, the device may not charge (due to the short circuit protection system). When stable, it will resume charging. It is normal for the device to feel slightly warm when charging.
-

Imported to Australia by:
Ni Concept (003 408 991)
Made in China

