


TK1069

Trekk Outdoor Speaker w/ Wireless Powerbank

Instruction Manual

Whats Included:

- 1x Trekk Outdoor Speaker
- 1x Micro-USB Charging Cable Underneath Speaker Packaging



Functions:

- 1. Wireless Charging Surface
- 2. Wireless Charging Phone Stand
- 3. USB Output
- 4. Micro-USB Input
- 5. Power LED indicator
- 6. AUX Port
- 7. Vol-/Previous Track
- 8. Play/Pause Button
- 9. Vol +/Next Track
- 10. Power Button
- 11. Bluetooth LED indicator
- 12. Wireless Charging ON/OFF Button
- 13. Microphone
- 14. Wireless Charging LED indicator

Instructions:

(Be sure to fully charge the speaker before *using for the first time*)

1. Charging the Speaker:

- Connect the provided 2Amp charging cable to a power source and to the micro USB input port(4) on the speaker.
- The 4 Power LED indicator(5) will flash BLUE when charging, and will all glow BLUE when fully charged.

2. Bluetooth® Setup:

- Press and hold the power button(10) to turn ON the speaker, the Bluetooth LED indicator(4) will quickly flash BLUE and speaker will tone when in bluetooth standby mode.
- Turn on the Bluetooth function of the mobile device, Select the "Trekk PB" pairing name.
- Speaker will tone and LED indicator will glow BLUE if successfully paired.
- Speaker will automatically pair if the mobile device has been paired before.
- Press and hold Speaker Power Button(10) to turn off the device.

** If the speaker isn't connected to *Bluetooth it will automatically power off after 5 minutes.*

3. Using the Speaker:

- Short press the Play/Pause Button(8) to pause or play music.

Tech Specifications:

- 1. Playing time: Up to 8hrs at max volume
- 2. Charging time: Up to 6hrs
- 3. Pairing Name: "Trekk PB"
- 4. Output: 5V/2A
- 5. Input: 5V/2A
- 6. Wireless Charging Output: 5V/1A(5W)

• "Vol+/Next track"(9):

- Short press - Increase volume
- Long press - Next track.

• "Vol-/Previous track"(7):

- Short press - Reduce volume
- Long press - Previous track

4. Calling:

- Short press the Play/Pause Button(8) to answer or end the call.
- Long press the Play/Pause Button(8) to reject the call.

5. Charging mobile phones and other electronic devices:

- Connect the appropriate charging cable to the mobile device or other electronic device.
- Connect the USB part of the cable into USB Output(3) LED indicator(5) will illuminate BLUE when charging.
- Remove the USB cable from your mobile device when it is fully charged.

6. Wireless Charging Function:

- Pull out the Wireless Charging Phone Stand(2) and place your phone horizontally onto the stand. The back of your device should be touching the Wireless Charging Surface(1).
- Press the Wireless Charging ON/OFF Button(12) to turn on wireless charging.
- The Wireless Charging LED Indicator(14)

will grow RED when charging.

- To turn OFF the wireless charging function, double press the wireless charging ON/OFF button(12).
- When wireless charging is turned on and not charging a device, Wireless Charging LED indicator(14) will be solid BLUE. After 35 seconds wireless charging will turn off if it's not charging a device.

** Note: When wireless charging, if the LED indicator flashes RED, there is an object between the device and charging surface interfering with the charging process.

Safety Precautions:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Never store or use this product in temperatures below 32°F(0°C) or above 115°F(45°C).
3. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles. Keep out of reach of children.
4. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
5. Do not expose the device to moisture.
6. Do not use the device in excess of its output rating.
7. Overload outputs above rating may result in a risk of fire or injury.
8. Do not use the device if damaged or modified.
9. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
11. Do not expose the device to fire or temperatures above 104°F may cause explosion.
12. Ensure that qualified service professionals use only identical replacement parts to ensure product safety.
13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

CAN ICES-3 (B) / NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada).

Imported to Australia by:
Ni Concept (003 508 991)
Made in China